



System Block Diagram.

Fig. 1



High Deficition Risthmanna Block Diagram

Fig 2



High Definition Transmission

Fig. 3





Fig. 5



700
A sink device initiates a key exchange -705
The Stb Self DCM indicates to the HNS Manager that -710 a Key exchange is Commencing
The HIUS Manager indicates  the Key exchange to the -715  copy protection Module.
The copy protection module authenticates the sink device -720 by sending AV/c commands using the services of the OSDFCM

Fig. 7